

## HARDWARE, END CAP

100352.



Installation and servicing of Danfoss Turbocor® compressors by qualified and product trained personnel only. Follow these instructions and sound refrigeration/electrical/servicing practices relating to installation, commissioning, maintenance, and service.

Consult the appropriate
Danfoss LLC Service Manual
on www.turbocoroem.com
for detailed service
instructions.

Never power compressor without covers in place and secured.

Removing the mains input cover will expose you to a voltage hazard of up to 853VDC. Ensure the mains input power is off and locked out before removing cover.

Before removing top cover, wait at least 20 minutes after isolating AC power to allow the high voltage capacitors to discharge.

Always wear appropriately rated safety equipment when from compressor in working around equipment and/or components energized with high voltage. is fully vented before the

This equipment contains hazardous voltages that can cause serious injury or death.

Recover all refrigerant accordance with local codes and ensure pressure removal of refrigerant containing components.

## 1 - Introduction

Please refer to our service manual for the removal and installation procedures.

To access the manual, you may scan the applicable QR code below or you may go to our DTC website at www.turbocoroem.com. At the bottom of the page there is a Section named "Categories" that includes various menus including one for Manuals.

Refer to the applicable QR code below to download the TT/TG Series Service Manual.







## 2 - Kit Contents

Note: Any part numbers included in this Kit Contents section are internal part numbers only. Please refer to our Spare Parts Manuals for any kit part numbers.

QTY	Part(s) Description	Picture(s)
1	O-RING – 901867	0
8	SCREW, M10X40, SOCKET HEAD CAP – 902847	
8	WASHER, M10, SPLIT LOCK – 902839	0
8	WASHER, M10, FLAT – 902836	0
1	LUBRICATION-SUPER-O-LUBE-2G – 900578	

## 3 - List of Changes

Revision	Date	Description of Change
	9/17/2024	Updated format
L		Added hardware to the kit contents
		Removed obsoleted kit numbers 100052 from the top of this document

Danfoss LLC can accept no responsibility for possible errors in catalogues, brochures, and other printed material. Danfoss LLC reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.

All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.